



CD/DVD CONFIGURATOR



CD4/CD4Q




DVD4/DVD4Q




Säule quadratisch (Q)
Vierkante buis (Q)

DVD11/DVD11Q




CD11/CD11Q




Säule rund
Ronde buis

CD10W/CD10WQ




CD10F/CD10FQ




Glasfuß (F)
Wandmontage (W)

Glazen voet (F)
Wandmontage (W)


DVD9W/DVD9WQ





DVD9F/DVD9FQ



CD108W/CD108WQ



DVD98W/DVD98WQ



1. Säulen quadratisch Vierkante buis

Aluminium (AL)
Aluminium (AL)

2. Säulen Buizen

Aluminium (AL)
Aluminium (AL)

Edelstahl (ES)
Edelstaal (ES)

Messing (MS)
Messing (MS)

3. Holz Hout

Buche (B)
Beuken (B)

Kirsch (K)
Kersen (K)

Schwarz (S)
Zwart (S)

Silber (Si)
Zilver (Si)



4. Glasauflagen Glass afwerking

Schwarzglas (BG)
Black glas (BG)

Klarglas (KG)
Helder glas (KG)

Mattglas (MG)
Mat glas (MG)

5. Extras Opties

CD-Stütze rund
(CDS-AL, CDS-ES
und CDS-MS) oder
quadratisch (CDS-ALQ)

CD-steun rond
(CDS-AL, CDS-ES
en CDS-MS) of
vierkant (CDS-ALQ)

